

## HOW TO INSTALL FLUID DESK SOFTWARE?

FLUID DESK software runs under AutoCAD (2015-2020 full version) and BricsCAD V20 Pro/Platinum/BIM. If you would like to work under BricsCAD you should download version supported by FLUID DESK.

### RUN FLUID DESK SOFTWARE UNDER BRICSCAD

To download BricsCAD and FLUID DESK tools you have to register on <https://www.fluid-desk.com/home/#>


1. Add your e-mail address and click download



office@gmail.com | Download

5.0.8 for BCV20 [EN-200304] | More download options

2. Register yourself



Fluid Desk

English

VENTPACK HYDRONICPACK FLM PARTSHEL24 ABOUT

I WOULD LIKE TO REGISTER AS A:

Designer  Component manufacturer

Student  Teacher  Others

First name Surname (required)

office@gmail.com Country (required) Phone (required)

Company / Organization (required) Activity profile (required)

City (required) Zip code (required)


Street / Number VAT Number

Password (required)  Subscribe to the newsletter.  Nie jestem robotem reCAPTCHA


Repeat password (required) Register I have an account

3. Confirm your registration checking your e-mail address


4. Choose More download option to download BricsCAD



5. On FLUID DESK PACKAGE VERSION choose BricsCAD only




6. Click Confirm (1) and Download (2)




7. Install BricsCAD

8. To download FLUID DESK software, choose on FLUID DESK PACKAGE VERSION 5.0



9. Click Confirm (1) and Download (2)




FLUID DESK software contains several modules

- FLM (FLUID DESK Library Manager)
- Hydronicpack (Heating and Cooling water systems)
- Project Explorer (Supporting multistory building)
- SLD (Single Line Drawing)
- Ventpack (Ventilation, smoke control, air-condition systems)
- All library

You can install whole package or chosen modules. FLM need to be always install because it is core module for running all others tools.

## RUN FLUID DESK SOFTWARE UNDER AUTOCAD


1. Add your e-mail address and click download



office@gmail.com | Download

5.0.8 for BCV20 [EN-200304] | More download options

2. Register yourself



**Fluid Desk** VENTPACK HYDRONICPACK FLM PARTSHELF24 ABOUT English

**I WOULD LIKE TO REGISTER AS A:**


Designer  Component manufacturer  
 Student  Teacher  Others

First name Surname (required)  
office@gmail.com Country (required) Phone (required)  
Company / Organization (required) Activity profile (required)  
City (required) Zip code (required)  
Street / Number VAT Number  
Password (required)  Subscribe to the newsletter.  Nie jestem robotem reCAPTCHA  
Repeat password (required) Register I have an account

3. Confirm your registration checking your e-mail address

4. Choose More Download Option

5. On FLUID DESK PACKAGE VERSION  
choose FLUID DESK 5.0



office@gmail.com | Download

5.0.8 for BCV20 [EN-200304] | More download options


**FLUID DESK PACKAGE VERSION:**  
BricsCAD ONLY | English

**CAD ENVIRONMENT:**  
BricsCAD V20

**AVAILABLE INSTALLERS:**  
BricsCAD V20.1.08-1 (English, 64-bit)

Confirm

6. In CAD ENVIRONMENT choose AutoCAD version



7. Click Confirm (1) and Download (2)



8. Install FLUID DESK SOFTWARE under AutoCAD.

FLUID DESK software contains several modules

- FLM (FLUID DESK Library Manager)
- Hydronicpack (Heating and Cooling water systems)
- Project Explorer (Supporting multistory building)
- SLD (Single Line Drawing)
- Ventpack (Ventilation, smoke control, air-condition systems)
- All library

You can install whole package or chosen modules. FLM need to be always install because it is core module for running all others tools.